


2430A

DIGITAL OSCILLOSCOPE USER REFERENCE GUIDE



Copyright © 1987 Tektronix, Inc. All rights reserved.
Contents of this publication may not be reproduced in any
form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered
by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and  are
registered trademarks of Tektronix, Inc.

Printed in U.S.A. Specification and price change privileges
are reserved.

INSTRUMENT SERIAL NUMBERS

Each instrument has a serial number on a panel insert, tag,
or stamped on the chassis. The first number or letter
designates the country of manufacture. The last five digits
of the serial number are assigned sequentially and are
unique to each instrument. Those manufactured in the
United States have six unique digits. The country of
manufacture is identified as follows:

B000000	Tektronix, Inc., Beaverton, Oregon, USA
100000	Tektronix Guernsey, Ltd., Channel Islands
200000	Tektronix United Kingdom, Ltd., London
300000	Sony/Tektronix, Japan
700000	Tektronix Holland, NV, Heerenveen, The Netherlands

Contents

	<i>Page</i>
Illustrations	iii
1 <i>Getting Started/Front Panel</i>	
Getting Started	1
Front Panel	3
2 <i>CRT Readout Display</i>	
CRT Readout Display	4
3 <i>Status/Help Menu</i>	
Status/Help Menu	5
4 <i>Powering Up</i>	
Powering Up	7
5 <i>CRT Display Menus</i>	
CRT Display Menus	9
6 <i>Auto Setup</i>	
Auto Setup	11
7 <i>PRGM Autostep</i>	
PRGM Autostep	12
8 <i>Measure</i>	
Measure	15
9 <i>Output</i>	
Output	19
10 <i>Vertical</i>	
Vertical	21

- 11 *Horizontal***
 - Horizontal..... 24
- 12 *Cursors***
 - Cursors 25
- 13 *Delay Functions***
 - Delay Functions 28
- 14 *Triggering***
 - Triggering 30
- 15 *A Triggering***
 - A Triggering 34
- 16 *B Triggering***
 - B Triggering 36
- 17 *Acquisition***
 - Acquisition 39
- 18 *Save and Display Reference***
 - Save and Display Rerence..... 41
- 19 *GPIB Status***
 - GPIB Status..... 43

Illustrations

<i>Figure</i>		<i>Page</i>
1	Front Panel Buttons and Controls.....	3
2	CRT Readout Display	4
3	Status Menu Display	5
4	POWER and MENU OFF Button.....	7
5	INTENSITY Control, SELECT and STATUS/HELP Buttons.....	9
6	AUTO SETUP Button	11
7	PRGM Button.....	12
8	MEASURE Button.....	15
9	OUTPUT Button.....	19
10a	Vertical Buttons and Controls	21
10b	Vertical Buttons and Controls	22
11	Horizontal Buttons and Controls	24
12	Cursor Buttons and Controls	25
13	Delay Buttons and Controls	29
14	Trigger CPLG, SET VIDEO, and SET WORD Buttons	30
15	Trigger SOURCE, INIT @50%, and TRIG STATUS Buttons.....	32
16	A Trigger MODE, TRIG POSITION, A/B TRIG Buttons.....	34
17	B Trigger A/B TRIG, CPLG, INIT @50%, MODE, TRIG POSITION SOURCE Buttons	36
18	Storage ACQUIRE Button.....	39
19	Storage SAVE and DISPLAY REF Button.....	41

1. The first part of the document discusses the importance of maintaining accurate records of all transactions and activities. It emphasizes that proper record-keeping is essential for transparency and accountability, particularly in the context of public administration and financial management. The text highlights that records should be kept in a clear, organized, and accessible manner, allowing for easy retrieval and verification of information.

2. The second part of the document focuses on the role of internal controls and risk management. It explains that these mechanisms are crucial for preventing fraud, errors, and mismanagement of resources. The text suggests that organizations should implement robust internal control systems that cover all aspects of their operations, from procurement to payroll. Additionally, it stresses the importance of regular risk assessments to identify potential vulnerabilities and develop strategies to mitigate them.

3. The third part of the document addresses the need for continuous improvement and learning. It argues that organizations should not be satisfied with the status quo but should actively seek ways to enhance their performance and efficiency. This involves fostering a culture of innovation and learning, where employees are encouraged to share their ideas and experiences. The text also mentions the importance of staying updated on the latest trends and best practices in the industry to remain competitive and effective.

4. The final part of the document concludes by summarizing the key points discussed and reiterating the importance of the discussed topics. It emphasizes that the implementation of these principles is not a one-time task but an ongoing process that requires commitment and dedication from all stakeholders. The text ends with a call to action, urging organizations to take immediate steps to address the identified areas for improvement and ensure the long-term success and sustainability of their operations.

GETTING STARTED

See Front Panel (Figure 1) for locating the controls on the 2430A.

Power On

Press the POWER switch, located on the front panel below the crt.

The 2430A performs a power-on test each time it is turned on. When the test progresses to the point of being able to display, the message "RUNNING SELF TEST" is shown on the crt. At the end of the self test, the message is removed.

If the 2430A fails the self test, it will enter the extended diagnostics (see below, MENU OFF/EXTENDED FUNCTIONS, for explanation). The 2430A may still be used if the failed area does not affect the measurements to be made. Press MENU OFF to exit extended diagnostic and enter Scope mode.

The CAL/DIAG menu displays the message "NOT WARMED UP" for ten minutes after each power-on.

Menu Off/Extended Functions

In the CAL/DIAG menu, PASS or FAIL indicates the results of the last calibration or self diagnostic run. No label will appear if calibration has not been run since the last cold start. If an "UNCALD" message appears in the extended diagnostics menu, it may indicate that the last attempt of extended calibration failed. Allow the 2430A to warm-up and do a SELF CAL, if the UNCALD message persists after a SELF CAL or some other area has failed, the previous calibration constants will not be overwritten, and the scope may be used. However, calibration should be checked by referring the instrument to a qualified service person. Press MENU OFF to exit extended diagnostics and enter Scope mode. More information on the self test and diagnostics is found in Appendix A of the Operators Manual.

Initialization

Connect a standard accessories P6133 probe to the CH 1 input BNC.

Connect the probe tip to the CALIBRATOR loop; connect the probe ground lead to scope ground.

Press the PRGM SETUP button, located below the A AND B SEC/DIV knob.

Select INIT PANEL menu choice by pressing the bezel button directly below the INIT PANEL menu label.

The initial settings for major front-panel controls are as follow:

VERTICAL MODE	CH 1
CH 1 and CH 2 VOLTS/DIV	1V (With 10X probe)
A AND B SEC/DIV	1 ms
TRIGGER MODE	AUTO LEVEL
TRIGGER SOURCE	VERT (CH 1)
Input Coupling	1 M Ω DC
STORAGE MODE	ACQUIRE
ACQUIRE MODE	NORM


Verify that CH 1 Vertical Mode is selected (CH1 VOLT/DIV readout is in upper left corner of crt). If CH 1 Vertical Mode is not selected then press Vertical MODE button and select CH 1 (See Section 10, Vertical Mode, of this guide.)

Press ACQUIRE button on front panel.

NOTE

Connecting a probe to the signal source and pressing the AUTO Setup front panel button will provide a scaled and triggered display. If no vertical channel is selected AUTO Setup will default to Channel 1. AUTO Setup will not change the channel selected if either or both of the 2 channels are on. If the display intensity is set too low and the scaled display is not easy to see, AUTO Setup boosts intensity so the display can be seen. AUTO Setup does not affect readout or graticule intensity. conflicting mode (causing the instrument to appear to operate incorrectly).

FRONT PANEL



6339-01

Figure 1. Front Panel Buttons and Controls.

CRT READOUT DISPLAY





Figure 2. CRT Readout Display.

STATUS MENU

IN THE READOUT, ACTIVE SECTIONS ARE UNDERSCORED.
IF BOTH A AND B HORIZONTAL MODE ARE UNDERSCORED,
THE HORIZONTAL MODE IS A INTEN.



6286-04

Figure 3. Status Menu Display.


The Status Menu display will appear on screen when the STATUS/HELP front panel button is selected. It provides an overview of instrument configuration at the time the selection is made. This menu will enable you to determine if you are currently operating in the desired modes, or if you are set in a conflicting mode (causing the instrument to appear to operate incorrectly). Special attention should be paid to the TRIGGER STATUS comment and the ACQ MODE statement in the lower left hand quadrant of the screen, which enable you to determine the instrument's current activity.

It is recommended that you become very familiar with this entire menu and the location and meaning of the readout characters because it will aid you in determining the cause of possible operational difficulties.

*Cold Start is a complete initialization of the system, done only at the factory.

POWERING UP

- ① **POWER Button** Does a power-on self test with each turn on. (See Section 1 for a more detailed description of POWER.)
- ② **MENU OFF/EXTENDED FUNCTIONS Button** Turns off any displayed menu or turns on the EXTENDED FUNCTIONS menu if a menu is not being displayed. When pressed to remove a menu display, all the scope hardware is reset to match the soft-front panel settings. Messages sent via GPIB will be erased. (See Section 1 for more detailed description of MENU OFF/EXTENDED FUNCTIONS.)



6339-02

Figure 4. POWER and MENU OFF Button.

Menu Off/Extended Functions Menu

2. MENU
OFF/EXTENDED
FUNCTIONS

Turns off any menu being displayed or, if none are on, calls up the EXTENDED FUNCTIONS menus. See Appendix A in the Operators Manual for the Extended Functions Calibration and Diagnostics menus:

EXT FUNCT

SYSTEM SPECIAL CAL/DIAG

Second-level menu for SYSTEM.

PREFLT

PANEL MISC ON:OFF VIDEO OPT

Third-level menu for SYSTEM PANEL.

PWR ON

LAST:INIT ↑

Third-level menu for SYSTEM MISC.

BELL TRIG T

ON:OFF ON:OFF ↑

Third-level menu for SYSTEM VIDEO OPT.

TV SYS CNT RST

M:NON/M BOTH:F1 ↑

Second-level menu for SPECIAL.

WARNING: SERVICE ONLY--SEE MANUAL (if enabled)
DISABLED--SEE MANUAL (if disabled)

COLD CAL PATH FORCE
START ON:OFF DAC

Second-level menu for CAL/DIAG.

<status> <status> <status> NOT WARMED UP
SELF EXT SELF EXT
CAL CAL DIAG DIAG

4

CRT DISPLAY MENUS

- ① **INTENSITY Control** Is a continuous rotating pot. Its controlling action remains directed to the last selected choice; except when STATUS is selected; it then becomes the readout intensity control.
- ② **SELECT Button** Toggles between readout and display after turning on the menu.




Figure 5. INTENSITY Control, SELECT and STATUS/HELP Buttons.

- ③ **STATUS/HELP Button** Pressing this button displays a Status menu, page 5, which is useful for determining why a display is not seen or triggering is not occurring. Some common conditions to check for are:

- Channel called up?
- Display intensity setting?
- Ground indicator (+) and trigger position (T) at top and bottom edges (vert. pos.)?

AUTO SETUP

- ① **AUTO SETUP Button** Selecting this button will cause the scope to set the vertical, horizontal, and triggers to display the input signal on the selected vertical channel or channels.

View Mode Selects sweep speed for 2-5 cycles on screen.
Other modes optimize scaling for selected signal type.




Figure 6. AUTO SETUP Button.

Auto Setup On-Screen Menus

1. AUTO SETUP	VIEW	PERIOD	PULSE	EDGE	RES
					HI:LO

NOTE

RES HI:LO only appears when in Measurement Modes, (i.e., PERIOD, PULSE, or EDGE).


PRGM AUTOSTEP

② PRGM Button

Selecting PRGM displays AUTOSTEP SEQUENCER menu which allows the user to save and recall typically 50 to 200 front panel setups, user prompts, and test procedures and associated control and I/O actions in up to 40 named procedures.

To save a single front panel:

1. Press PRGM (Program) on front panel.
2. Select SAVE bezel button.
3. Select SAVE bezel button, second level.
4. Set up front panel that you want to save.
5. Press PRGM (Program) button on front panel.
6. Press SAVE SEQ bezel button.



6339-05

Figure 7. PRGM Button.

Autostep Sequencer Control Menus

2. PRGM

```

-----AUTOSTEP SEQUENCER----- MEMORY nn%
SAVE   RECALL  DELETE  EDIT   INIT
                                           PANEL
    
```

Second-level menu for SAVE.

USE ARROW KEYS TO CHANGE NAME:

```

-----
ROLL-CHARS      CURSOR
  ↑             ↓      < >   SAVE   EXIT
    
```

Instruction message displayed after pushing SAVE. (This message is displayed any time the user is expected to setup the front-panel controls.)

SETUP CONTROLS, PUSH PRGM TO CONTINUE
 SEQUENCE <name> STEP <num> MEMORY <%>

Third-level menu for second-level SAVE. This menu is displayed after pushing PRGM as instructed in the instruction message.

```

SEQUENCE <name> STEP <num> MEMORY <%>
BEGIN STEP
REPEAT      <N>
SELF-CAL    <N>  PRINT/PLOT    <N>
SELF-TEST   <N>  BELL              <N>
LOAD PANEL  SRQ   <N>
AUTOSETUP   <N>  PAUSE             <N>
MEASUREMENTS PROJECT <N>
                                END STEP
    
```

SET STEP ACTIONS

```

                                NEXT   SAVE
                                STEP   SEQ
  ↑             ↓             Y;N
    
```

7

Autostep Sequencer Control Menus (cont)

Second-level menu for RECALL.

First Labeled Sequence
 Second Labeled Sequence
 nth Labeled Sequence

-----SELECT-----

↑ ↓ RECALL EXIT

Second-level menu for DELETE.

First Labeled Sequence
 Second Labeled Sequence
 nth Labeled Sequence

-----SELECT-----

↑ ↓ DELETE EXIT

Second-level menu for EDIT.

First Labeled Sequence
 Second Labeled Sequence
 nth Labeled Sequence

-----SELECT-----

↑ ↓ EDIT COPY EXIT

Third-level menu for EDIT.

-----SELECT----- DELETE

↑ ↓ TO BUF ADD EXIT

Third-level menu for COPY.

USE ARROW KEYS TO CHANGE NAME:

ROLL-CHARS CURSOR
 ↑ ↓ < > SAVE EXIT

Fourth-level menu for ADD.

LOAD
 BUFFER EXIT

7

MEASURE

③ **MEASURE
Button
(Waveform
Parameter
Extraction)**

Pressing this front panel button displays MEASURE menu on screen.

Provides selects for measurement type, setup and snapshots.

NOTE

In MEASURE menu, MARK ON selection turns on "X" markers that indicate measurement locations, i.e., 10%-90% risetime locations.

NOTE

If WINDOW menu is selected, time cursors must be manually selected. The cursors can then be set to bracket the portion of the waveform to be measured.




Figure 8. MEASURE Button.

Measure Menus

3. MEASURE

	MEAS	SETUP	DISPLAY	WINDOW
SNAPSHOT	TYPE		ON:OFF	ON:OFF

Second-level menu for SNAPSHOT when more than one display source is displayed.

TARGET:

CH1	CH2	MULT/ADD	REF
-----	-----	----------	-----

Resulting display when either SNAPSHOT is pressed and only one display source is on screen or when the TARGET waveform is selected.

SNAPSHOT READOUT:

SNAPSHOT OF CHx USING MIN/MAX METHOD:

DIS=4.35 V	TOP=5.01 V	WID=20.3 μ S
MES=2.12V	BASE=2.00 mV	DUTY=50%
PRX=-1.23 mV	MEAN=2.32 V	FREQ=24.6 kHz
MAX=5.15 V	OVRS=2.0%	PER=40.6 μ S
MID=2.47 V	UNDS=1.0%	RISE=28.4 nS
MIN=21.4 mV	RMS=2.65 V	FALL=18.3 nS
P-P=5.36 V	AREA=47.5 nVs	

DIST=90.0%	MES=50.0%	PROX=10.0%
AGAIN		↑

↑: Returns the scope to the MEASURE Menu.

AGAIN: Initiates another snapshot.

8

Measure Menus (cont)

Second-level menu for SETUP.

.....METHOD.....	MARK
MIN/MAX HIST CURSOR	LEVEL ON:OFF

This menu is used to set up criteria for extraction of LEVEL. Pushing the menu button labeled LEVEL displays a third level menu which allows the DISTAL, MESIAL, and PROXimal levels on the waveform to be specified.

Third-level menu for LEVEL.

ADJUST LEVELS WITH CURSOR/DELAY KNOB				
nn%	nn%	n.nV	nn%	
DISTAL	MESIAL	PROXIMAL	MESIAL2	%:VOLT

Second-level menu for MEAS TYPE.

MEAS TYPE: The continuous parameter extraction function is executed by selecting up to four parameters for display from a parameter matrix. Pushing the menu button labeled MEAS causes the Parameter Selection menu to be displayed:

DISTAL	MESIAL	PROX	MAX	MID
MIN	PK-PK	TOP	BASE	MEAN
OVRSH	UNDRSH	RMS	AREA	WIDTH
DUTY	FREQ	PERIOD	RISE	FALL
DELAY				
-	-	1	ON	OFF

Measure Menus (cont)

Third-level menu for MEASTYPE when more than one display source is displayed and DELAY is not selected in the parameter matrix.

TARGET:

CH1 CH2 MULT/ADD REF

Selection of DELAY as the parameter to be extracted causes a different third- and fourth-level TARGET menu to be displayed:

Third-level menu for MEASTYPE when more than one display source is displayed and DELAY is selected in the parameter matrix.

DELAY FROM

TARGET:

CH1 CH2 MUL/ADD REF

Fourth-level menu for MEASTYPE when more than one display source is displayed and DELAY is selected in the parameter matrix.

DELAY TO

TARGET:

CH1 CH2 MUL/ADD REF

8

OUTPUT




Figure 9. OUTPUT Button.

OUTPUT Control Menus

4. OUTPUT

STATUS SETUP DEBUG TRANSMIT/(PRINT)

STATUS calls up an on-screen display of most GPIB parameters that a system user might be interested in.

TRANSMIT/(PRINT) switches to ABORT when the function is active. TRANSMIT/(PRINT) is off in OFF BUS mode.

Second-level menu for GPIB SETUP.

OUTPUT SETUP
MODE TERM ADDR ENCDG

Third-level menu for GPIB MODE.

T/ONLY L/ONLY T/L DEVICES OFF BUS

Selecting DEVICES changes TRANSMIT to PRINT in the OUTPUT control menu. Selecting OFF BUS turns off the TRANSMIT/PRINT choice.

Fourth-level menu for DEVICES.

HPGL THINKJET
PLOTTER PRINTER SETUP

Fifth-level menu for SETUP.

SETTINGS TEXT GRAT WFM PGSIZE
ON:OFF ON:OFF ON:OFF ON:OFF US:A4

VERTICAL

① **VERTICAL POSITION Controls**

CH 1 is the HORIZONTAL POSITION control in XY mode.

② **VARIABLE Buttons**


CH 1 VARIABLE uncalibrates the ADD mode readout, but the CH 2 VARIABLE does not. This feature lets users input a sample of an unwanted signal into CH 2 and adjust the CH 2 VARIABLE to cancel the unwanted signal in the ADD display. See Section 3 of the Operators Manual for use of this feature.

Arrow (1 and 1) menu button functions are continuous when held down. CAL returns V/D to calibrated setting.

③ **VOLTS/DIV Switches**

Readouts automatically adjust to the correct readout scale factor when 1X, 10X, 100X, and 1000X TEK coded-attenuator probes are attached.

VOLTS/DIV is the vertical expansion control in SAVE storage mode and the extended range control in AVG ACQUIRE mode.



6339-09

Figure 10a. Vertical Buttons and Controls.

4 **MODE Button**

Initiates Vertical MODE menu on screen. Active selections are underscored.


The resultant signal of a MULT display is scaled down by a factor of 5.12 to maintain the display within the graticule area.

ADD and MULT are not displayed in ENVELOPE mode.

XY mode automatically turns on the CH 1 and CH 2 signals REF 1 vs REF 2, may be displayed as XY REF.

NOTE

In this menu, CH 1, CH 2, ADD and MULT buttons are push/push; one push turns the mode on, another turns it off. Also, selecting ADD turns MULT off and visa-versa. Pushing YT:XY toggles the mode between YT and XY. Functions are underscored when turned on.



6339-10

Figure 10b. Vertical Buttons and Controls.

- 5 **COUPLING/ INVERT Buttons** May be used to switch through the available coupling choices after menu is called up.

AC coupling and 50 Ω termination are mutually exclusive.


- 6 **BANDWIDTH Button** May be used to scroll through menu choices after menu is called up.

Vertical On-Screen Menus

2. VARIABLE	CH1 VARIABLE				
	CAL	↓			↑
4. VERTICAL MODE	In YT Mode.				
	VERTICAL MODE	CH1	CH2	ADD	MULT
5. COUPLING INVERT	In XY Mode.				
	VERTICAL MODE	CH1 vs CH2			YT:XY
6. BANDWIDTH	CH1 COUPLING				
	AC	DC	GND	50 Ω ON:OFF	INVERT ON:OFF
6. BANDWIDTH	CH2 COUPLING				
	AC	DC	GND	50 Ω ON:OFF	INVERT ON:OFF
6. BANDWIDTH	USB=xxxxHz USR=xxxx s				
BANDWIDTH.....				SMOOTH ON:OFF
20 MHz 50 MHz FULL					
The number xxxx depends on the Acquisition Mode, the SEC/DIV setting, and the bandwidth selected.					

HORIZONTAL

- ① **A Button** Activates A sweep function.
- ② **A AND B SEC/DIV Switch** Determines sweep rate for A and B sweep functions. Used in SAVE mode to horizontally expand display. Do not change horizontal mode after entering SAVE storage mode if using horizontal expansion. ROLL mode replaces AUTO Mode in the A TRIGGER mode menu for A SEC/DIV settings ≤ 100 ms/div.
- ③ **A INTEN Button** Selects A INTENSified operating mode. SEC/DIV control (2) controls the B SEC/DIV.
- ④ **B Button** Selects B Delayed sweep operation. A AND B SEC/DIV will now control B sweep rate.



6339-12

Figure 11. Horizontal Buttons and Controls.


CURSORS

- 1 FUNCTION Button** Displays CURSOR FUNCTION menu on screen.

To review the ATTACH CURSORS menu of a selected CURSOR FUNCTION while in another menu, press the function button twice, or turn off and then back on the selected cursors.
- 2 UNITS Button** Displays UNITS menu on screen.
- 3 SELECT Button** Selects which cursor the CURSOR/DELAY knob (4) controls.

NOTE

No cursor, regardless of type, can be positioned off screen; all cursors are bound at the screen perimeter. For cursor functions displaying time cursors, attempting to move either cursor past either edge of the screen causes the display to horizontally reposition. Pressing SELECT moves the bound cursor to center screen.



6339-13

Figure 12. Cursor Buttons and Controls.

4 **CURSOR/DELAY Control** Controls active cursor positioning, adjusts DELAY TIME or DELAY EVENTS.

When time cursors are displayed and active, the CURSOR/DELAY knob may be used to scroll through the entire record length. Cursors will operate similarly for reference waveforms when attached to a displayed reference waveform.

CURSOR/DELAY knob is a shared control; positions cursors for cursor functions; sets delay times or delay events number for DELAY functions.

NOTE

Bezel buttons operate in a push/push mode, selecting and deselecting function. Selection of alternate function will deselect a previous mode.

Cursor On-Screen Menus

1. FUNCTION	CURSOR FUNCTION				
	VOLTS	TIME	V@T	SLOPE	1/TIME
	Second-level menu for a CURSOR FUNCTION selection.				
	In YT Mode.				
	ATTACH CURSORS TO:				
	No Δ delay				
	CH1	CH2	(func)	(func) Δ	REF n
	Δ delay—CH1 on				
	CH1	CH1 Δ	(func)	(func) Δ	REF n
	Δ delay—CH1 and CH2 on				
	CH1	CH2 Δ	(func)	(func) Δ	REF n
	Function is either ADD or MULT; they are mutually exclusive. Pressing REF rolls through the displayed reference waveforms. Only waveforms called up for display are included in the ATTACH CURSORS menu.				
	In XY Mode (with CH1 vs CH2 and XYREF selected).				
	ATTACH CURSORS TO:				
	CH1 vs CH2		XYREF		

12


Cursor On-Screen Menus (cont)

2. UNITS	In VOLTS or V@T.				
	UNITS		VOLTS CURS REF = xxxxxx		
	VOLTS	%	dB	NEW REF	Δ!ABS
	In SLOPE.				
UNITS		SLOPE CURS REF = xxxxxx			
SLOPE	%	DEGREES	NEW REF		
In 1/TIME.					
UNITS		1/TIME CURS REF = xxxxxx			
Hz	%	DEGREES	NEW REF	Δ!ABS	
In TIME.					
UNITS		TIME CURS REF = xxxxxx			
SEC	%	DEGREES	NEW REF	Δ!ABS	

DELAY FUNCTIONS

- ① **CURSOR/DELAY Control** Sets delay times or delay event number for Delay functions. It defaults to cursors control when neither Delay function menu is displayed.
- ② **EVENTS Button** Selects DELAY by EVENTS function and connects events count selection to CURSOR/DELAY control knob (1).
- ③ **TIME Button** Selects DELAY by TIME, and switches between Main Delay and Delta Delay functions. CURSOR/DELAY control knob (1) is used to set time delay.

Triggers must be supplied via the B trigger circuitry to obtain Event triggering when EVENTS is on. A delayed by B events and B delayed by time may be used sequentially.



6339-14

Figure 13. Delay Buttons and Controls.

Delay On-Screen Menus

2. DELAY by EVENTS	EVENTS START AT A TRIG EVENTS COUNT = xxxxx B TRIGS	EVENTS ON:OFF
3. DELAY by TIME	With Δ TIME OFF.	
	DELAY TIME = xxxxxx B	Δ TIME ON:OFF
	With Δ TIME ON.	
	DELAY TIME = xxxxxx B Δ DELAY TIME = xxxxxx B	Δ TIME ON:OFF
DELAY by TIME button is pressed to switch the CURSOR/DELAY position knob between the Main DELAY TIME and the Δ (delta) DELAY TIME when Δ TIME is ON.		

TRIGGERING

- 1 CPLG Button** Switches through the menu choices (except VIDEO) when pushed repeatedly.
- 2 SET VIDEO Button** Displays Video Trigger mode selection menu (on scopes equipped with Video trigger only). In addition, Video coupling is selected via the A TRIGGER COUPLING menu.

Video signal must be interlaced for field 2 to appear in on-screen readout.

- 3 SET WORD Button** Displays the Word Recognizer Probe configuration menu.




Figure 14. Trigger CPLG, SET VIDEO, AND SET WORD Buttons.

- 4 **SOURCE Button** Toggles between 1 and 2 if channel or external trigger is the selected source.
- A and B trigger conditions must be met to obtain a trigger in A 'AND' B. 'AND' source is not available for B Trigger. An attempt to select WORD as the trigger source without a WORD Recognizer Probe attached, displays the message "WORD PROBE FAULT". SOURCE remains as the last valid choice. EXTERNAL GAIN selection made from second-level of Trigger SOURCE menu.
- 5 **INIT 50% Button** Causes the 2430A to do a single Auto Level Trigger cycle automatically setting the trigger level at 50% of peak-to-peak signal value.
- 6 **TRIG STATUS Button** Activates the TRIGGER STATUS menu, which details the current Trigger mode, Source, Coupling and Trigger position selection for the A and B triggers.





Figure 15. Trigger SOURCE, INIT @50%, and TRIG STATUS Buttons.

Trigger On-Screen Menus (cont)

4. TRIGGER SOURCE	<p>A TRIG SOURCE</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">VERT</td> <td style="width: 25%;">CHAN</td> <td style="width: 25%;">EXT</td> <td style="width: 25%;"></td> </tr> <tr> <td>CH1</td> <td>1:2</td> <td>1:2</td> <td>LINE A*B:WORD</td> </tr> <tr> <td>CH2</td> <td></td> <td></td> <td></td> </tr> <tr> <td>ADD</td> <td></td> <td></td> <td></td> </tr> </table>	VERT	CHAN	EXT		CH1	1:2	1:2	LINE A*B:WORD	CH2				ADD			
	VERT	CHAN	EXT														
CH1	1:2	1:2	LINE A*B:WORD														
CH2																	
ADD																	
<p>Second-level menu for A EXT.</p> <p>A EXT SOURCE -----A AND B EXT GAIN----- 1:2 EXT 1 EXT 1/5 EXT 2 EXT2/5</p>																	
6. TRIG STATUS	<p>TRIG STATUS</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 25%;">A*B MODE</td> <td style="width: 25%;">SOURCE</td> <td style="width: 25%;">CPLG</td> <td style="width: 25%;">TRIG POS</td> </tr> <tr> <td>---</td> <td>-----</td> <td>---</td> <td>-----</td> </tr> </table> <p>A (Setup conditions for the A Trigger Controls.) B (Setup conditions for the B Trigger Controls.)</p>	A*B MODE	SOURCE	CPLG	TRIG POS	---	-----	---	-----								
A*B MODE	SOURCE	CPLG	TRIG POS														
---	-----	---	-----														

A TRIGGERING

- 7** **MODE Button** Steps through the mode choices, except SINGLE SEQ, when pushed repeatedly.
- 8** **TRIG POSITION Button** Steps through the menu choices when pushed repeatedly.
- 9** **A/B TRIG Button** Selects between A and B Trigger menu displays for configuration, SLOPE, MODE, SOURCE, CPLG, LEVEL and TRIG POSITION controls are shared by A and B trigger system.




6339-18

Figure 16. A Trigger MODE, TRIG POSITION, A/B TRIG Buttons.

B TRIGGERING

- 9 **A/B TRIG Button** Switches the effect of the trigger controls between the A and B trigger systems.
- 10 **CPLG Button** Switches through the menu choices when pushed repeatedly.
- 11 **INIT 50% Button** Causes the 2430A to do a single Auto Level Trigger cycle automatically setting the trigger level at 50% of peak-to-peak signal value.
- 12 **MODE Button** Toggles between RUNS AFTER and TRIG AFTER when pressed repeatedly.

EXT CLK ON sets the time cursor readouts and the delay time numbers to units of CLK. A clock signal must be provided via the B trigger circuitry to obtain triggering.



6339-20

Figure 17. B Trigger A/B TRIG, CPLG, INIT @50%, MODE, TRIG POSITION, SOURCE Buttons.

- 13 **TRIG POSITION Button** Displays the control menu used to select the Record Trigger position in the waveform display.
- 14 **SOURCE Button** Displays the B TRIGGER SOURCE menu.

B Trigger On-Screen Menus

10. TRIGGER CPLG	<p>In B TRIG AFTER Delay Mode.</p> <p>B COUPLING B, EXT CLK CPLG (with EXT CLOCK ON) B, EVENTS CPLG (with DELAY by EVENTS ON) B, CLK, EVENTS (with both ON)</p> <p style="text-align: center;">-----REJECT-----</p> <p style="text-align: center;">DC AC NOISE HF LF</p> <p>In B RUNS AFTER Delay Mode.</p> <p>B COUPLING EXT CLK CPLG (with EXT CLOCK ON) EVENTS COUPLING (with DELAY by EVENTS ON) EVENTS, CLK (with both ON)</p> <p style="text-align: center;">-----REJECT-----</p> <p style="text-align: center;">DC AC NOISE HF LF</p>				
12. TRIGGER MODE	B TRIG	RUNS AFTER	TRIG AFTER	EXT CLK ON/OFF	
13. TRIG POSITION	<p>B TRIGGER POSITION</p> <p style="text-align: center;">1/8 1/4 1/2 3/4 7/8</p>				

B Trigger On-Screen Menus (cont)

14. TRIGGER SOURCE

In B TRIG AFTER Delay Mode.

B TRIG SOURCE

B, EXT CLOCK SOURCE (with EXT CLOCK ON)

B, EVENTS SOURCE (with DELAY by EVENTS ON)

B, EXT CLK, EVNT SOURCE (with both ON)

SOURCE

VERT	CHAN	EXT	WORD
CH1	1:2	1:2	
CH2			
ADD			

In B RUNS AFTER Delay Mode.

B TRIG SOURCE

EXT CLK SOURCE (with EXT CLOCK ON)

EVENTS SOURCE (with DELAY by EVENTS ON)

EVENTS, EXT CLK SOURCE (with both ON)

SOURCE

VERT	CHAN	EXT	WORD
CH1	1:2	1:2	
CH2			
ADD			

Second-Level menu for B EXT.

B EXT

SOURCE -----A AND B EXT GAIN-----

1:2 EXT 1 EXT 1/5 EXT 2 EXT 2/5

ACQUISITION

① ACQUIRE Button

Starts/restarts the acquisition from SAVE mode. If SINGLE SEQ trigger mode is on, turn it off to gain access to the ACQUIRE menu when fast completing sequences are being acquired.


At the completion of a single seq acquisition, the scope switches to SAVE storage mode.

Save On Delta will be automatically turned off upon entering SAVE when a discrepancy is detected between the reference envelope and the live waveform. If GPIB mode is set for PRINTER output, screen data will be printed, then Save On Delta will be reinitialized to continue monitoring the incoming live acquisitions (not done in ROLL mode).

If GPIB mode is selected for the talk/listen mode, the 2430A will issue a SRQ notifying the Controller of the SAVE event.

Average and Envelope acquisitions in progress will be restarted by any of the following front-panel control changes:

1. Any vertical or horizontal mode change.
2. A volts/div setting change of either channel.



6339-21

Figure 18. Storage ACQUIRE Button.

3. A vertical position change of either channel. (Average but not Envelope.)
4. Input coupling changes to either channel.
5. Changes in the Trigger mode.
6. Pressing the MENU/OFF button to turn off menus.
7. Delay-by-Events or Delay-by-Time changes (Average only).
8. Changing the trigger slope.

These results are seen on screen:

ENVELOPE turns off ADD or MULT vertical mode choices. REPET mode extends bandwidth to 150 MHz for repetitive waveforms.

Storage On-Screen Menus

1. ACQUIRE	ACQUIRE	nnn	nnn	REPET	SAVE ON Δ
	NORMAL	ENVELOPE	AVG	ON!OFF	ON!OFF
nnn selections:					
ENVELOPE—1,2,4,8,16,32,64,128,256,CONT					
AVG—2,4,8,16,32,64,128,256					

SAVE AND DISPLAY REFERENCE

- ① **SAVE Button** Entered at the end of: a SINGLE SEQ, a discrepancy with Save On Delta reference, as a result of pressing the SAVE front-panel button, and temporarily during an XY plotter or printer output. Pressing STACK REF in the SAVEREF SOURCE menu treats the reference memories as a stack: waveforms are saved in a predetermined reference memory, depending on what is displayed.
- ② **DISPLAY REF Button** Toggles between DISPLAY and HORIZONTAL position selection menus.




Figure 19. Storage SAVE and DISPLAY REF Button.

Storage On-Screen Menus (cont)

1. SAVE	-----SAVEREF SOURCE-----	STACK	
	CH1 CH2 (function) REF	REF	
	Second-level menu for a SAVEREF SOURCE selection (except REF or STACK REF). If REF is selected, or Δ DELAY TIME is turned on while B is the HORIZONTAL MODE setting, this menu becomes a third-level menu.		
	-----SAVEREF DESTINATION-----	SAVEREF	
	REF1 REF2 REF3 REF4	SOURCE	
Second-Level menu for SAVEREF SOURCE in Δ (delta) DELAY by TIME.			
SAVEREF SOURCE---(channel)			
DELAY 1 DELAY 2			
Second-Level menu for REF.			
SAVEREF SOURCE---REF		SAVEREF	
REF1 REF2 REF3 REF4		SOURCE	
2. DISPLAY REF	In YT Mode.		
	DISPLAY REF		
	REF1 REF2 REF3 REF4		HORIZ POS REF
	EMPTY appears above reference menu choice if no valid waveform is stored.		
	In XY Mode.		
	XYREF		HORIZ POS REF
	Second-level menu for HORIZ POS REF. (In YT Mode.)		
----HORIZONTAL POSITION----		REF HPOS	
REF1P REF2P REF3P REF4P		IND!LOCK	
Second-level menu for HORIZ POS REF. (In XY Mode.)			
----HORIZONTAL POSITION----		REF HPOS	
XY REFP		IND!LOCK	

GPIB STATUS


GPIB Status On-Line Screen

CH1 100mV	A 1ms	35.2mV EXT1
ADDR 3	RQS ON	START = 256
MODE THINKJET	OPC ON	STOP = 512
TERM EOI	CER ON	
	EXR ON	EVENTS
FASTXMIT	EXW ON	NONE
OFF	INR ON	
1 WFMS REQSTD	PID OFF	
RIBINARY	USER OFF	
SOURCE CH1	PATH ON	
TARGET REF1	LONG ON	
ENCDG RIBINARY	DEBUG OFF	
BINWFM-SCOPE RI	DEVDEP ON	

The GPIB Status menu will appear on screen when STATUS is selected from the output menu. The underscored items are configurable functions while the remainder of the listings will vary with current instrument setup.

Interpretation of GPIB STATUS menu listings:

ADDR =	ADDRESS SELECTION	RQS =	ASSERT SRQ IF PENDING EVENT
MODE =	MODE SELECTION	OPC =	ASSERT SRQ ON OPERATION COMPLETE
TERM =	TERMINATION	CER =	ASSERT SRQ ON COMMAND ERROR
SOURCE =	WAVEFORM DATA SOURCE	EXR =	ASSERT SRQ ON EXECUTION ERROR
TARGET =	WAVEFORM DATA TARGET	EXW =	ASSERT SRQ ON EXECUTION WARNING
ENCDG =	ENCODING	INR =	ASSERT SRQ ON INTERNAL ERROR
BINWFM =	INCOMING BINARY WAVEFORM INTERPRETATION MODE	PID =	ASSERT SRQ ON PROBE IDENTIFICATION
		USER =	ASSERT SRQ ON BEZEL BUTTON PUSH
		PATH =	SEND COMPLETER PATH IN QUERY RESPONSE
		LONG =	USE LONG FORM IN QUERY RESPONSE
		DEBUG =	TURN ON DEBUG MODE
		DEVDEP =	ASSERT SRQ IF TRANSMIT PUSHED
		401 =	POWER ON SRQ (TYPICAL EVENT)



For further information, contact:

U.S.A., Asia, Australia, Central & South America, Japan

Tektronix, Inc.
P.O. Box 1700
Beaverton, Oregon 97075
For additional literature, or the address and phone number of the Tektronix Sales Office nearest you, contact:

Phone: (800) 547-1512
Oregon only: (800) 452-1877
Telex: (910) 467-8708
TLX: 151754
Cable: TEKWSGT

Europe, Africa, Middle East


Tektronix Europe B.V.
European Headquarters
Postbox 827
1180 AV Amstelveen
The Netherlands
Phone: (20) 471146
Telex: 18312-18328

Canada

Tektronix Canada Inc
P.O. Box 6500
Barrie, Ontario L4M 4V3
Phone: (705) 737-2700

Tektronix sales and service offices around the world:

Albania, Algeria, Argentina, Australia, Austria, Bangladesh, Belgium, Bolivia, Brazil, Bulgaria, Canada, Peoples Republic of China, Chile, Colombia, Costa Rica, Czechoslovakia, Denmark, East Africa, Ecuador, Egypt, Federal Republic of Germany, Fiji, AWA New Zealand, Finland, France, Greece, Hong Kong, Hungary, Iceland, India, Indonesia, Ireland, Israel, Italy, Japan, Jordan, Korea, Kuwait, Lebanon, Malaysia, Mexico, The Netherlands, New Zealand, Nigeria, Norway, Pakistan, Panama, Peru, Philippines, Poland, Portugal, Qatar, Republic of South Africa, Romania, Saudi Arabia, Singapore, Spain, Sri Lanka, Sudan, Sweden, Switzerland, Syria, Taiwan, Thailand, Turkey, Tunisia, United Arab Emirates, United Kingdom, Uruguay, USSR, Venezuela, Yugoslavia, Zambia, Zimbabwe.

Copyright © 1985 Tektronix, Inc. All rights reserved. Printed in U.S.A. Tektronix products are covered by U.S. and foreign patents issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX, TEK SCOPE, MOBILE and  are registered trademarks. For further information contact Tektronix, Inc. Corporate Offices, P.O. Box 500, Beaverton, OR 97077. Phone: (503) 627-7111. TWX: (910) 467-8708. TLX: 151754. Cable: TEKWSGT. Subsidiaries and distributors worldwide.

Tektronix
COMMITTED TO EXCELLENCE